





















Original		Replacement		Original		Replacement	
	Power		Power		Yellow		Yellow
	Play		Play		Blue		Blue
	Pause		Pause		CH+		Ch +
	<<		<<		CH-		Ch -
	>>		>>		Source		AV
	I<<		I<<		Vol+		Vol +
	>>I		>>I		Vol-		Vol -
	Stop		Stop		Menu		Menu
	TV/TXT		Text		Rec		Rec
	Cancel		Eject		Up		Up
	Reveal		D. Menu		Down		Down
	Hold		Media		Right		Right
	Size		3D		Left		Left
	Subpage		Shift + Subt		OK		Ok
	Index		List		DVB		Smart
	Red		Red		Exit		Exit
	Green		Green		1		1



