



















































Original		Replacement		Original		Replacement	
	Power		Power		6		6
	Output Level-		Vol -		7		7
	Output Level+		Vol +		8		8
	Hi-Lite Scan		TV/R		9		9
	Random Play		Ok		10		0
	<< Manual		<<		>10		Guide
	Manual >>		>>		PGM		AV
	I<< Track		I<<				
	Track >>I		>>I				
	Stop		Stop				
	Pause		Pause				
	Play		Play				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				

