

















































Original	Replacement	Original	Replacement
 Power	 Power	 Rec	 Rec
 D/A Input	 Shift + AV	 I<<	 I<<
 Tv/Radio	 TV/R	 <<	 <<
 Input	 AV	 >>	 >>
 Bright -	 Shift + Left	 >>	 >>
 Bright +	 Shift + Right	 Back	 Back
 Simplink	 Media	 DVR	 Smart
 Text	 Text	 Menu	 Menu
 Info	 Info	 Exit	 Exit
 Live TV	 Shift + Smart	 Guide	 Guide
 Red	 Red	 Up	 Up
 Green	 Green	 Right	 Right
 Yellow	 Yellow	 Down	 Down
 Blue	 Blue	 Left	 Left
 Stop	 Stop	 OK	 Ok
 Play	 Play	 Vol+	 Vol +
 Pause	 Pause	 Vol-	 Vol -





















































Original	Replacement	Original	Replacement
 FAV	 Pre Ch	 [=i]/Index	 Shift + Info
 Mute	 Mute	 [=o]/Time	 Shift + Exit
 PR+	 Ch +	 Sleep	 Sleep
 PR-	 Ch -	 [=+]/Hold	 3D
 1	 1	 [=?]/Reveal	 Options
 2	 2	 Subtitle	 Subt
 3	 3	 Ratio	 Format
 4	 4	 I/II	 Dual
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 List	 List		
 Q.View	 D. Menu		
 [=x]/Update	 Eject		





Original		Replacement		Original		Replacement	
	Power		Power		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	Pause		Pause		7		7
	I<<		I<<		8		8
	<<		<<		9		9
	>>		>>		0		0
	>>I		>>I				
	Menu		Menu				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	OK		Ok				
	1		1				
	2		2				
	3		3				



