







































































Original		Replacement		Original		Replacement	
	Power		Power		i+/Info		Info
	Stop		Stop		≡/Options		Options
	Pause		Pause		Back		Back
	Rec		Rec		≡/List		List
	<<		<<		Up		Up
	Play		Play		Down		Down
	>>		>>		Right		Right
	Ambilight		Media		Left		Left
	*/Setup		Menu		OK		Ok
	[<>]/Format		Format		Vol+		Vol +
	Sources		AV		Vol-		Vol -
	Home		Smart		Mute		Mute
	TV/Exit		Exit		Tv Guide		Guide
	Red		Red		CH+		Ch +
	Green		Green		CH-		Ch -
	Yellow		Yellow		1		1
	Blue		Blue		2		2



