







































Original	Replacement
 Power	 Power
 Time	 Shift + AV
 Sleep	 Sleep
 Call	 Media
 TV/AV	 AV
 I/II	 Dual
 Zoom	 Eject
 Nothing	 TV/R
 DVB	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Replacement
 9	 9
 0	 0
 +/-	 Shift + Guide
 QV	 Pre Ch
 PgUp	 Shift + Ch +
 PgDn	 Shift + Ch -
 P+	 Ch +
 P-	 Ch -
 V+	 Vol +
 V-	 Vol -
 - P -	 Format
 - S -	 Shift + Dual
 TV Menu	 Menu
 DVB Menu	 D. Menu
 Mute	 Mute
 Esc	 Exit
 Up	 Up





Original	Replacement
 Down	 Down
 Right	 Right
 Left	 Left
 Select	 Ok
 Guide	 Guide
 Info	 Info
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Text	 Text
 Subtitle	 Subt
 Mix	 Shift + Text
 Index	 Shift + Info
 Size	 Shift + Eject
 Hold	 Stop
 Cancel	 Back

Original	Replacement
 Reveal	 Options

