

























































| Original | | Replacement | | Original | | Replacement | |
|---|------------------|---|------------|---|---------------|---|------|
|  | Power |  | Power |  | 4/VGA |  | 4 |
|  | Freeze |  | Pause |  | 5/Component |  | 5 |
|  | Hide |  | Info |  | 6/Video |  | 6 |
|  | Aspect/Ratio |  | Format |  | 7/DVI |  | 7 |
|  | Resync |  | Media |  | 8/HDMI |  | 8 |
|  | Source |  | AV |  | 9/Wireless |  | 9 |
|  | Zoom |  | Shift + Up |  | 0 |  | 0 |
|  | e |  | 3D |  | Mute |  | Mute |
|  | Up / Keystone+ |  | Up |  | PgUp/Contrast |  | Ch + |
|  | Left |  | Left |  | PgDn/S.Video |  | Ch - |
|  | Menu |  | Menu | | | | |
|  | Menu |  | Ok | | | | |
|  | Right |  | Right | | | | |
|  | Down / Keystone- |  | Down | | | | |
|  | 1/RGB |  | 1 | | | | |
|  | 2/Brightness |  | 2 | | | | |
|  | 3/Color |  | 3 | | | | |

