













Original	Replacement
	 Power
	 Info
	 Options
	 Sleep
	 Format
	 AV
	 3D
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Back

Original	Replacement
	 0
	 Menu
	 Red
	 Green
	 Yellow
	 Blue
	 Up
	 Down
	 Right
	 Left
	 Ok
	 Ch +
	 Ch -
	 Vol +
	 Vol -
	 Pre Ch
	 Dual





Original	Replacement	Original	Replacement
	Subtitle		Subt
	Mute		Mute
	Swap		Smart
	EPG		Guide
	[*]/[.]		D. Menu
	Text		Text
	C		Media
	Display		Shift + Info
	Angle		Eject
	Search Mode		TV/R
	Rec		Rec
	Stop		Stop
	Play		Play
	Pause		Pause
	<<		<<
	>>		>>
	I<<		I<<

