








| Original  | Replacement  |
|---|--|
|  Power         |  Power                |
|  Mute          |  Mute / Dimmer        |
|  1             |  1                    |
|  2             |  2                    |
|  3             |  3                    |
|  4             |  4                    |
|  5             |  5                    |
|  6             |  6                    |
|  7             |  7                    |
|  8             |  8                    |
|  9             |  9                    |
|  *(Left)     |  Shift + Left      |
|  0           |  0                  |
|  *(Right)    |  Shift + Right     |
|  [ ]/Picture |  Picture / Format  |
|  /Sound      |  Sound / Title     |
|  I-II        |  Audio / Lang I/II |

| Original   | Replacement  |
|--|--|
|  Menu       |  Menu / Home                |
|  Up/PR+     |  Up                         |
|  PR+        |  CH+ / Page+                |
|  List       |  Smart / List               |
|  Vol-       |  Vol-                       |
|  Left       |  Left                       |
|  OK         |  OK                         |
|  Right      |  Right                      |
|  Vol+       |  Vol+                       |
|  Sleep      |  Sleep / Timer              |
|  Down/PR-   |  Down                       |
|  PR-      |  CH- / Page-              |
|  P<P      |  Back / Return            |
|  Tv/AV    |  AV / Input / RDS         |
|  Tv/PC    |  TV/Radio /               |
|  [<>]/ARC |  Shift + Picture / Format |
|  Red      |  Red / Netflix / Search   |





| Original                  | Replacement                           | Original | Replacement            |
|---------------------------|---------------------------------------|----------|------------------------|
|                           | Green / APP / Repeat                  |          | SHIFT +  Shift + Down  |
|                           | Yellow / YouTube / Repeat             |          | SHIFT +  Shift + CH- / |
|                           | Blue / Prime Video / Random           |          |                        |
|                           | Text / Goto                           |          |                        |
| [.≡]/Mix button"/>        | SHIFT +  Shift + Text /               |          |                        |
| [≡◆]/Size button"/>       | SIZE / Zoom / Size                    |          |                        |
| [≡i]/Index button"/>      | ANGLE / Info / Angle                  |          |                        |
| [≡x]/Update button"/>     | REC MODE / Rec / Rec Mode             |          |                        |
| [≡o]/Time button"/>       | STEP - FREEZE / Pause / Step / Freeze |          |                        |
| [≡?]/Reveal button"/>     | SLOW / Play / Slow                    |          |                        |
| [≡+]/Hold button"/>       | HOLD / Stop / Hold                    |          |                        |
| [ ■ ]/PIP button"/>       | MEDIA / Display / Media               |          |                        |
| [ : ■ ]/Input button"/>   | SHIFT +  Shift + AV / Input / RDS     |          |                        |
| [ / ■ ]/Swap button"/>    | SHIFT +  Shift + Back / Return        |          |                        |
| PIP PR+ button"/>         | SHIFT +  Shift + CH+ /                |          |                        |
| [- ■ ]/Position button"/> | SHIFT +  Shift + Display / Media      |          |                        |
| [.≡]/Mode button"/>       | SHIFT +  Shift + Smart / List         |          |                        |

