







































Original	Replacement
 Standby/On	 Power
 Input Select	 AV
 HDMI	 D. Menu
 Open/Close/Eject	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Setup	 Options
 Clear	 Exit
 Prog+	 Ch +

Original	Replacement
 Prog-	 Ch -
 Timer/Prog	 Sleep
 [i+]	 Info
 Text	 Text
 Variable Skip/→	 Media
 Variable Replay/→	 Smart
 Guide	 Guide
 Top Menu	 Shift + Menu
 Menu/List	 Menu
 Display	 Shift + Info
 Return/Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter/OK	 Ok
 Red	 Red





Original	Replacement
 Green	 Green
 Yellow/System	 Yellow
 Blue/Search	 Blue
 <<	 <<
 Play	 Play
 >>	 >>
 I<<	 I<<
 Stop	 Stop
 >>I	 >>I
 Pause	 Pause
 VCR	 Shift + 1
 HDD	 Shift + 2
 DVD	 Shift + 3
 Time Shift	 List
 Dubbing	 Pre Ch
 Rec Speed	 3D
 Rec	 Rec

Original	Replacement
 Subtitle	 Subt
 1.3x/0.8xPlay	 Format
 Audio	 Dual
 Sat.Link	 TV/R
 A1	 Shift + Subt

