







































































Original	Replacement	Original	Replacement
	Power		Power
	Open / Close		Eject
	Angle		Format
	Zoom		Shift + Eject
	Program		Sleep
	Random		3D
	Repeat / A-B		Text
	HDMI		AV
	<< REV		<<
	>> FWD		>>
	I<< Skip		I<<
	>>I Skip		>>I
	Pause		Pause
	Play		Play
	Stop		Stop
	Clear		Exit
	Disc Menu		D. Menu
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	OK		Ok
	Preview		Smart
	Set Up		Options
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0





	Original	Replacement		Original	Replacement
	Display	 Info			
	Audio	 Dual			
	Subtitle	 Subt			
	Mute	 Mute			
	Bookmark	 Pre Ch			
	Title Menu	 Menu			

